



GolfSim Designer Cut Series

ImpactWhite™ A4K Golf Simulation Projection Material

Model# RM-6.6x12-IPWA4K

Care & Use


The **Designer Cut A4K** is a pre-cut ImpactWhite A4K golf screen material. ImpactWhite A4K is a single-layer tightly weaved front projection material designed to provide exceptional imaging characteristics for ultra-high definition projectors with the ability to also perform as a Golf Impact or Multi-sport simulation screen.

Elite Screens wants you to enjoy your **Designer Cut ImpactWhite A4K** for many years to come! We made the Designer Cut materials available for you to be able to fully customize your screen project. Please note that ALL Designer Cut are raw materials that require specific properties to be adhered during installation to obtain an enjoyable viewing experience.

Installation Tips and Precautions

PROJECTION/IMPACT SIDE

1. Please make note on the label on the material to indicate the projection side. See pictures for reference.



2. Never place your screen over a window or under consistent sun exposure. Solar radiation breaks down synthetic projection materials, so it is best to keep them away from direct sunlight.

Installation Tips and Precautions

1. Make sure to use the correct side. The ImpactWhite™ A4K screen should have a back label.
2. Make sure to allow proper distance for swing range to protect children, pets, ceilings, walls, windows, or any other property.
3. Avoid using golf balls with scuffs or markings to maximize the life of your ImpactWhite™ A4K screen. If possible, use new golf balls.
4. Never place the screen over a window or under constant sun exposure. Solar radiation from direct sunlight destroys the synthetic fibers of the screen.

Maintenance

Wrinkles/Creases:

- The material may have minor wrinkles which will get removed after stretching it over a frame or a mounting system that allows tensioning. You can also use a handheld fabric steamer to remove wrinkles or creases.

Dust/Dirt:

- A feather duster should be used to remove loose dirt or dust. Use warm water with a toothbrush to clean dirt or dust spots. **Do not use soap as it will stain the material.**
- Don't use acetone, benzene, alcohol, and any other organic solvents to clean the screen material. Using such chemicals will permanently damage the screen.

We take great care in packaging the **Designer Cut** series of materials so that they arrive at your doorstep with zero issues. Should your screen arrive with any shipping damage or show signs of damage, we urge you to contact us directly so that we can provide a speedy resolution – we always strive for the best customer experience and are here to help.

**For Technical Support or an Elite Screens contact in your area,
visit www.elitescreens.com**